

INTERNAL PADDING GUIDE

U9121
**UDG ULTIMATE
CD PLAYER/MIXER BAG LARGE MK2**

This guide illustrates how to configure
the internal padding correctly



UDG
UDGEAR.COM

EQUIPMENT

PIONEER DJS 1000 : **B + C + E**
PIONEER DJM 750MK2 : **A + B + C**
PIONEER DJM 900 NXS2 : **A + B + C**
PIONEER DJM 850 : **A + B + C**
PIONEER DJM 700 : **A + B + C**
PIONEER DJM 750 : **A + B + C**
PIONEER DJM S9 : **A + B + C + D + E**
PIONEER DJM T1 : **A + B + C + D + E**
PIONEER DJM 900SRT : **A + B + C**
ALLEN & HEATH XONE 62 : **A + B + C**
ALLEN & HEATH XONE 43C : **A + B + C + E**
NI TRAKTOR Z2 : **A + B + C + D + E**
RANE SEVENTY-TWO : **A + D**
RANE TTM 57MK2 : **A + B + C + D + E**
RANE TTM 56S : **A + B + C + D + E**
RANE MP 2015 : **A + B + C**
RANE MP 2014 : **A + B + C + D**
RANE SIXTY TWO / TWO Z : **A + B + C + D + E**
RANE SIXTY EIGHT : **A + B + C**
RANE SIXTY FOUR : **A + B + C + E**
RELOOP KUT : **A + B + C + E**
RELOOP RMX-80 : **A + B + C**
RELOOP RMX-60 : **A + B + C**
RELOOP RMX-90 DVS : **A + B + C**
DENON X1800 PRIME SERIES : **A + E**
MODEL1 : **A + E**

