



# INTERNAL PADDING GUIDE

This guide illustrates how to configure the internal padding correctly for a selection of popular DJ controllers.



A B C D E F G H are for side padding  
1 2 3 4 5 6 7 8 are for base padding

Illustrations for making base padding



Flip the padding 90 degrees

# INTERNAL PADDING GUIDE

This guide illustrates how to configure the internal padding correctly for a selection of popular DJ controllers.

## EQUIPMENT

Pioneer DDJ RR	Use Side Padding	A B C D E F
	Use Base Padding	7 8
Pioneer DDJ SX/SX2	Use Side Padding	A E
	Use Base Padding	7 8
Pioneer DDJ SR	Use Side Padding	A B C D E F
	Use Base Padding	7 8
Pioneer DDJ S1/T1	Use Side Padding	E F
	Remove Base Padding	
Pioneer XDJ R1	Use Side Padding	A B E F G
	Remove Base Padding	
Pioneer XDJ AERO	Use Side Padding	A B E F G
	Use Base Padding	3 4
Denon DJ MC 7000	Use Side Padding	B F
	Use Base Padding	7 8
NI Traktor Kontrol S8	Use Side Padding	A B C D
	Use Base Padding	7 8
Numark NS 6	Use Side Padding	A B C E F
	Use Base Padding	7 8
Numark 4Trak	Use Side Padding	A B
	Remove Base Padding	
Reloop Terminal Mix 8	Use Side Padding	A B C D E
	Use Base Padding	7 8