



CODE-LOCK INSTRUCTION

The original number is 0-0-0, to set your personal combination, please follow these steps:


1. Open the lock (The original number is 0-0-0).




2. Press the Reset Button with a pen (or other tools) all the way until you hear the "Click" sound.



3. Set number your secret combination by turning the dials (for example 8-8-8).



4. Pull the Button rightward to the open position and let Reset Button to be back.



Now your personal code is set. Remember your personal combination. If you want to change to a new combination, repeat steps 1-4.

